



BOOMERANG THROWING INSTRUCTIONS



Ted Bailey
 3245 Edgewood Dr.
 Ann Arbor, MI 48104
 (734)-971-2970
 boomflight@gmail.com

© 1994



These instructions are for the novice thrower. If you have never thrown a boomerang before, please read and memorize these instructions before you attempt to throw. If you are left handed (yes, there is a difference), please apply mirror image symmetry to these instructions.

Always throw the boomerang with just a small amount of layover (/). A pinch grip is better than wrapping your finger around the tip.




Throw Level →



Throw with as much spin as possible.

For more info on boomerang activities, write to the address above.


Curved side towards you.



The boomerang should be thrown nearly parallel to the ground

The (RH) boomerang should be thrown nearly 50 degrees to the right of the oncoming wind. If the boomerang cuts in front of you and lands to your right, then you threw too far to the right and you need to throw more to the left. If the boomerang circles behind you and lands to your left, then you threw too far to your left and you need to throw more to the right.

THE WIND



Lands to the left: It was thrown too far to the left.

Lands to the right: It was thrown too far to the right.